

**HIKOKI****CORDLESS GRASS TRIMMER/BRUSH CUTTER CG3**

Item No.	Code No.	Description	No. Used	Remarks
1	6601339	HEX. SOCKET HD. BOLT (W/SP.WASHER) M5X22	1	
2	305574	HEX. SOCKET HD. BOLT (W/SP.WASHER) M5X16	1	
3	328643	TAPPING SCREW (W/FLANGE) D4X23 (BLACK)	10	
4	379350	MV LABEL (B) (2)	1	
5	380100	HOUSING (A).(B) SET	1	
6	378666	HEX. SOCKET HD. BOLT (W/SP.WASHER) M5X22	4	
7		NAME PLATE	1	
8	380112	PIPE HOLDER	1	
9	380113	BEARING HOLDER	1	
10	361221	ROTOR	1	
*11	341163	WIRING ASS'Y	1	INCLUD.12,13 FOR AUS (L),NZL (L)
*12	380104	SWITCH PANEL CABLE	1	FOR MODEL (L)
13	379931	BATTERY TERMINAL	1	
14	379349	MV LABEL (A) (2)	1	
15	380099	TAPPING SCREW (W/FLANGE) D3X12	2	
16	373311	CORD CLIP	1	
*17	380116	INTERNAL WIRE (EMC)	1	FOR AUS,NZL,EUROPE
18	380114	FRONT COVER (A).(B) SET	1	
20	335752	LOCK LEVER	1	
21	380107	TAPPING SCREW D3X12	2	
24	339250	TAPPING SCREW (W/FLANGE) D4X20	6	
25	335239	LEVER	1	
26	380106	TRIGGER SPRING	1	
*29	949556	NUT M6 (10 PCS.)	2	FOR MODEL (L)
*30	6696975	LOOP HANDLE	1	FOR MODEL (L)
*31	6696973	BARRIER	1	FOR MODEL (L)
*32	6696974	BOLT (BLACK) M6	2	FOR MODEL (L)
33	6699439	GEAR CASE ASS'Y (4BB)	1	INCLUD.34-43
34	6600005	CAP	1	
35	6600006	SPRING	1	
36	6684737	BOLT (W/PLUS) M6X8	1	
37	6600007	LOCK PIN	1	
38	6699441	CUTTER HOLDER (A)	1	
39	6698659	CUTTER HOLDER (B)	1	
40	6699188	NUT COVER	1	
41	335759	U-NUT (LEFT HAND) M10	1	
42	6695414	SCREW 5X12/W.S	1	
43	949664	HEX. SOCKET HD. BOLT M5X30 (10 PCS.)	1	
*44	6601432	NYLON HEAD ASS'Y	1	INCLUD.45-49 EXCEPT FOR EUROPE
*45	6698795	SET SCREW	1	EXCEPT FOR EUROPE
*46	6698796	REEL	1	EXCEPT FOR EUROPE
*47	6698797	RETURN SPRING	1	EXCEPT FOR EUROPE
*48	6698798	BUTTON	1	EXCEPT FOR EUROPE
*49	6698799	CORD GUIDE	2	EXCEPT FOR EUROPE
*54	6684714	HEX. HOLE BUTTON BOLT M6X25	2	FOR MODEL (L)
55	66A4598	HANGER ASS'Y	1	
*58	380115	HANDLE (A).(B) SET	1	FOR MODEL (L)
59	377257	DRIVE SHAFT	1	
*60	377256	MAIN PIPE	1	EXCEPT FOR EUROPE
61	6699443	COVER BRACKET	1	
62		CAUTION LABEL (B)	1	
*64	6600446	LEVEL MARK (B)	1	FOR MODEL (L)
65	380102	GUARD (EU)	1	

\* ALTERNATIVE PARTS

**HIKOKI****CORDLESS GRASS TRIMMER/BRUSH CUTTER CG3**

Item No.	Code No.	Description	No. Used	Remarks
66	380103	COVER GUARD (EU) ASS'Y	1	INCLUD.67,68A
67	6684751	TAPPING SCREW 4X14	1	
68A	381414	KNIFE	1	
		STANDARD ACCESSORIES		
501	6684764	BOX WRENCH (HEX. SOCKET 17/19)	1	
502	6684813	HEX. BAR WRENCH 4MM	1	
*503	875769	PROTECTIVE GLASSES	1	EXCEPT FOR EUROPE
504	380075	POUCH CLOTH	1	
505	6684768	CUTTER COVER	2	
*506	330787	SHOULDER BELT	1	EXCEPT FOR EUROPE
507	380117	BLADE 3TX255XT1.8	1	

\* ALTERNATIVE PARTS

