


# PARTS LIST

## 1. Model WR 14A



ITEM	PART NAME	QTY
101	HAMMER CASE	1
102	PACKING	1
103	HAMMER CASE BUSHING	1
104	SOCKET RETAINER	1
105	O-RING	1
106	ANVIL	1
106A	ANVIL UNIT	1
107*	HAMMER FRAME PIN	2
108*	HAMMER	2
109*	HAMMER FRAME	1
110	HAMMER CASE GREASE FITTING	1
201	HOUSING	1
202	REGULATOR	1
203	SPRING	1
204	PIN	1
205	HALF ROUND HD. HEX. BOLT	4
206	TRIGGER BUSHING B	1
207	O-RING	1
208	SEAL	1
301	BEARING	1
302	CYLINDER UNIT	1
303	BLADES	6
304	ROTOR	1
305	PIN	1
306	REAR BEARING PLATE	1
307	HEX. SOC. HD. BOLT	3

ITEM	PART NAME	QTY
308	BEARING	1
309	O-RING	1
310	REVERSE VALVE	1
312	LATCH SPRING BUSHING	1
313	O-RING	1
314	FLAT WASHER	1
315	BOLT ASSY	1
317	REVERSE VALVE A	1
318	REVERSE VALVE B	1
319	FLAT HD. SCREW	1
321	SEAL	1
401	INSERT BUSHING	1
402	O-RING	1
403	SEAL	1
404	BUSHING	1
405	TIP VALVE	1
406	SPRING	1
407	MUFFLER	1
408	EXHAUST DEFLECTOR	1
409	TAP BOLT	1
410	O-RING	2
411	AIR INLET	1
412	SPRING PIN	1
413	TRIGGER UNIT	1
414	SPRING	1
415	O-RING	1