


PARTS LIST



ITEM	PART NAME	QTY
101	HOUSING	1
201	REGULATOR	1
202	VALVE STEM	1
203	O-RING	1
204	O-RING	2
205	S-RING	1
206	SEAL	1
207	TIP VALVE	1
208	CONICAL SPRING	1
209	AIR INLET	1
210	SPRING PIN	1
211	TRIGGER	1
215	AIR PLUG	1
301	FRONT RING	1
302	BEARING	1
303	FRONT BEARING PLATE	1
304	ROTOR	1
305	BLADES	5
306	CYLINDER	1
307	LINE-UP PIN	1
308	REAR END PLATE	1
309	BEARING	1
310	REAR RING	1

ITEM	PART NAME	QTY
311	MIDDLE RING	1
312	WASHER	1
313	LOCK RING SEAL	1
314	MOTOR SHAFT BALANCER	1
315	ROTOR KEY	1
316	BEARING	1
317	BEARING SHIELD	1
318	SNAP RING	1
319	BALANCER SHAFT	1
320	VACUUM-SHROUD	1
321	SNAP RING	1
322	BEARING SEAL	1
323	6" PAD (6) HOLES HOOK	1
324	HEAT ISOLATION WASHER	2
325	BEARING SEAL	1
401	MUFFLER SCREW	1
402	MUFFLER	1
403	MUFFLER CAP	1
407	VACUUM ADAPTER-CENTRAL VAC	1
408	HALF ROUND HD. HEX. BOLT	1
409	U-NUT	1